

PULL OFF ADHESION TESTER CODE ISQ-PF200

- To measure the pull off adhesion of paint coating on metal, wood, plastic, etc.
- According to ISO 4624, EN13144



VIDEO



Ø15.1mm flat dolly
(included)



Ø19.5mm flat dolly
(included)



ring cutter (included)



glue (included)
ISQ-PK100-1



glue for rough surface
(included) ISQ-PK100-2

SPECIFICATION

Test range	Ø15.1mm flat dolly	1~10MPa
	Ø19.5mm flat dolly	2~6MPa
Minimum size of test sample		30×30mm
Dimension		70×70×150mm
Weight		1kg



step 1: glue the dolly
on the paint coating



step 2: cut the paint around
dolly by using ring cutter



step 3: rotate the handwheel,
read the adhesion
when dolly is pulled off

STANDARD DELIVERY

Main unit	1pc
Ø15.1mm flat dolly	3pcs
Ø19.5mm flat dolly	3pcs
Ring cutter	1pc
Glue (ISQ-PF200-1)	3g
Glue for rough surface (ISQ-PF200-2)	6ml